

PRE-INSTALLATION NOTES



NOTE: Supplemental Installation System only for trucks with Deck Rails.

Additional Hardware Kit is provided with your installation package. Use the included 1-inch Bolts in place of the traditional 1 ¼-inch and the Square Nut Plates in place of the C-Clamps. Use washers and lock washers from traditional kit to work with 1-inch bolts and square nut plates.

DECK RAIL INSTALLATION INSTRUCTIONS

Installation of Hardware using Deck Rail System on Toyota Tundras

- 1** You must remove Deck Rail end caps before installing deck rail brackets. If you have Tundra accessories such as tie-down cleats, you can either slide them to the center of the deck rail or you may have to remove them prior to installing UnderCover bracket system (**See Picture #A for removing end caps and Picture #B for how your deck rail will look once both UnderCover brackets are installed and your Tundra accessories such as the cleats are also installed**).
- 2** Follow the instructions for installing the Rear Mounting Brackets in Step #1, on Page 3, the difference is that you will need replace the C-clamps with the Deck Rail Square Nuts provided in the extra package. These Square Nut Plates slide into the Deck Rail and hold the Rear and Front Mounting Brackets in place with the 1-inch bolt and washers. **See pictures C & D** on how to insert and bolt the square nut plates to the deck rail. Once you have installed Rear Mounting Brackets this would be a good time to slide-in your Tundra cleats back into place before putting the Front Mounting Bracket in place.
- 3** Follow the instructions for installing the Front Mounting Brackets in Step 2, on Page 5, but like the Rear Brackets mentioned above, slide in the Deck Rail Square Nut plates in place of the C-clamps and use 1-inch bolts and washers to secure front mounting bracket (**See Pictures E & F**).



NOTE: All of your instructions for mounting the UnderCover onto the Brackets are the same as the traditional instructions listed in this installation guide by following Steps 1, 2 and 3 for securing the cover to the bed. Be sure that all bolts are tightened down properly before proceeding.

TOYOTA TUNDRA DECK RAIL SYSTEM

